


1/4, 3/8 and 1/2 NPTF Swivel Mount Counterbalance Valves







	0	
ļ		Ų



- Optional Manual Release
- .0000522 cc/min Leak Rate
- Adjustable Load Setting
- Direct Mounting Swivel

Basic Operation:

The counterbalance valve will hold a load in position until pressure or an external force is applied to move the load. Turning the adjusting screw clockwise will increase the load carrying capacity of the valve. Optional manual and flush manual release.

Operating Data:

Max. Pressure:120 psiLeak Rate:.000052Temp. Range:30-150Cycle Rate:1 cyc./sFlow Capacity (Cv):2.6Cracking Pressure:1-2 psiService:Propert

120 psi .0000522 cc/min. 30-150 F 1 cyc./sec. 2.6 1-2 psi Properly filtered dry and lubricated air.

MODELS	1/4 Swivel	3/8 Swivel	1/2 Swivel		
1/4 NPTF Input Port					
No Manual Release	B4SC00-25	B4SC00-38	B4SC00-50		
Manual Release	B4SC0M-25	B4SC0M-38	B4SC0M-50		
Flush Manual Release	B4SCFM-25	B4SCFM-38	B4SCFM-50		
3/8 NPTF Input Port					
No Manual Release	B6SC00-25	B6SC00-38	B6SC00-50		
Manual Release	B6SC0M-25	B6SC0M-38	B6SC0M-50		
Flush Manual Release	B6SCFM-25	B6SCFM-38	B6SCFM-50		

