


1/2 and 3/4 NPTF Pneumatic Counterbalance Valves









- Optional Manual Release

- .0000522 cc/min Leak Rate

- Adjustable Load Setting

Basic Operation:

The counterbalance valve will hold a load in position until pressure or an external force is applied to move the load. Turning the adjusting screw clockwise will increase the load carrying capacity of the valve. Optional manual and flush manual release.

Operating Data:

Max. Pressure: Leak Rate: Temp. Range: Cycle Rate: Flow Capacity (Cv): Cracking Pressure: Service: 120 psi .0000522 cc/min. 30-150 F 1 cyc./sec. 3.8 1-2 psi Properly filtered dry and lubricated air.

MODELS	1/2 NPFT	3/4 NPFT	
No Manual Release	B81C00	B121C00	
Manual Release	B81C0M	B121C0M	
Flush Manual Release	B81CFM	B121CFM	



(Tel) 262 782-6125 www.NGTValves.com